

QZ 3322

Polyimide Stripper

QZ3322 is a specially designed formulation for stripping uncured polyamic acid and photocrosslinked polyimide in the uncured (softbaked) form.

Product Specifics	
Storage conditions	Ambient to 4°C
Shelf life	36 months
Packaging	4 x 4 L HDPE bottle
	Other configuration are available upon request

Note: Fully cure polyimide cannot be easily removed by wet chemical means. Plasma ashing (O₂/CF₄ 5:1) is the most effective method.

Wet Strip Process:

The following is a typical procedure for removing softbaked, photocrosslinked polyimide.

1. NMP at 85°C for 5 minutes
2. QZ3322 polyimide stripper at 70°C for 5 minutes
3. NMP at room temperature for 5 minutes
4. DI water rinse, dry completely

The data contained in this technical bulletin is believed to be true and accurate, but is offered solely for your consideration, investigation, and verification. Nothing herein shall be construed to be a warranty or guarantee by the Fujifilm Electronic Materials manufacturer ("FFEM") or any of its affiliates, and all such warranties, implied or otherwise, including any express or implied warranty of merchantability or fitness for a particular purpose, are hereby expressly disclaimed. You are fully responsible for any use and/or domestic or foreign sales of the product(s) described. Nothing in this technical bulletin shall be construed to constitute permission or a recommendation to use or practice any invention covered by a patent or patent application or know-how owned by FFEM, its affiliates, or others. Please refer to the material safety data sheet (MSDS) for complete information on storage and handling, toxicological properties, personal protective equipment, first aid, spill and leak procedures, and waste disposal. To order an MSDS, call your FFEM sales office. Before using or handling this product, review the MSDS information thoroughly.

FUJIFILM
www.fujifilm-ffem.com

**European Headquarters
Fujifilm Electronic Materials
(Europe) N.V.**

Keetberglaan 1A
Havennummer 1061
B-2070 Zwijndrecht
Belgium
Telephone : 32-3-250-0511
Fax : 32-3-252-4631

**Fujifilm Electronic Materials
U.S.A., Inc.**

6550 South Mountain Road
Mesa, Arizona 85212
U.S.A.
Telephone : 1-480-987-7536
Fax : 1-480-987-7104

**Worldwide Headquarters
Fujifilm Electronic Materials, Co., Ltd.**

15th Arai-BLDG, 6-19-20
Jingumae Shibuya-Ku
Tokyo 150-0001
Japan
Telephone : 81-3-3406-6911

Fujifilm Electronic Materials U.S.A., Inc.

Quonset Point
80 Circuit Drive
North Kingstown, Rhode Island 02852
U.S.A.
Telephone : 1-800-553-6546